

Radio Operating Instructions

Licensee: J C Beachey Licence No. 1074198/1



Operation

Switch on by turning knob B (rotate fully for full volume)

Select channel by rotating knob A (it will tell you the channel number). You will be told which channel to use (there are 7).

To transmit press and hold in the large side button, let go to receive.

IMPORTANT

Listen first to make sure no-one else is transmitting, then you can transmit.

Tips

No chatter, keep transmissions short.

Address messages to "control" giving your name or radio number and location.

The names of lost or found children must not be mentioned by radio!

The radio alert codes are:

- **"code amber"** = situation developing needs supervision
- **"code red "** = situation needs immediate intervention
- **"code purple"** = situation requires maximum support from all response staff
- **"code green"** = return to normal

Safety Risk Assessment

Operate 2 to 3 inches from your mouth (minimal radiation hazard)

Do not touch the antenna whilst transmitting (moderate radiation hazard and reduced signal)

Do not operate within 25 metres of a Petrol station or where there is likelihood of escaping gas (moderate risk of explosion)

Do not operate within 15 metres of a suspicious object/package (risk of triggering explosion)

Avoid operating whilst driving (not an offence in itself but could cause distraction)